

With the **HYDRO-BLOK™** product range you can build a BETTER Shower System easier & faster than traditional showers

HYDRO-BLOK™ Shower System	Traditional Shower Install
✓ Simple installation for DIY'ers or contractors	Slow and difficult installation best left to specialty contractors
✓ Environmentally friendly lightweight products with CFC-free XPS foam core	Heavy materials including cement base and wall-board
✓ All products are fully waterproof	Requires application of a full waterproof membrane before tile/stone can be applied
✓ Easy to make repairs & maintain waterproofing	Difficult & costly to repair and re-waterproof
✓ About 2-3 hours for standard 3 x 3 shower install	Minimum 2 to 3 days for shower install
✓ Shower allows for movement or deflection	Movement or deflection can crack shower
✓ Excellent choice for RV's, yacht or cruise ship installation	Can not be used in any moving application with good long term results
✓ No additional vapour barrier required for standard shower	Vapour barrier must be installed when built on an outside wall
✓ Cutting of product is dust free and quick	Grinding cement or cutting wallboard creates extensive dust
✓ System accessories provide easy customization without increasing install time significantly	Customizing is costly & labour/time intensive
✓ 10-year warranty on HYDRO-BLOK foam products	No manufacturer warranty on cement base/liner
✓ Cement surface is true and level for tile or stone installation	Time/labour intensive to get a true and level surface with membrane application
✓ Speed and ease of installation for commercial applications can not be beat	Difficult, heavy, and time-consuming to customize for commercial applications
✓ All foam products tested 100% mold-proof	Highly prone to mold growth and water saturation

