

HYDROBLOK®

The BETTER Shower System

EASIER
QUICKER
BETTER
Shower Systems



What is the HYDROBLOK Advantage?

HYDROBLOK allows you to design and construct a 100% waterproof shower in less time than a traditional construction methods.

- 💧 Lightweight & Extremely Strong.
- 💧 Pre-built niches and benches.
- 💧 Building board for custom features.
- 💧 Ready to water test and install tile after 1-2 hrs.
- 💧 Foam components can be easily customized with simple tools.

HYDROBLOK® lets you build a 100% waterproof Shower System *easier & faster* than traditional install methods.

💧 Installation Comparison:

HYDROBLOK®

Installer (Usually the Tile Setter)

**Install & Tile
Same Day!**

1. Install HYDROBLOK Pan and Wallboard

- 💧 Build benches and features to exacting specifications without relying on other trades using HYDROBLOK 1.5" or 2" thick wall board.
No additional framing is required.
- 💧 HYDROBLOK can be water tested immediately after installation.
- 💧 HYDROBLOK is dimensionally stable so curbs, benches and niches will not move, preventing future leaks.

Traditional Mortar & Membrane Shower Install*

**2-3 Days
Before Tiling***

Framing for Shower/Features

Carpenter frames features such as benches, curbs and niches.

System Install AND Waterproofing 2-3 Days Labor

1. Apply first mortar base for pan. **(Wait 24 Hrs)**
2. Install pan liner and wall board.
3. Install final mortar slope for pan. **(Wait 24 Hrs)**
4. Apply liquid or fabric membrane waterproofing to the wall board. **(Wait 12-24 Hrs)**
5. Apply second coat of liquid membrane. **(Wait 24 Hrs)**

*Based on typical installations. May not represent all situations.

HYDROBLOK®

1-844-588-9559 | www.hydroblok.com

Demos and complete instructions at
www.youtube.com/HYDROBLOK



Save Time & Money with the HYDROBLOK Advantage:

	HYDROBLOK®	Traditional System*	Sheet Membrane System*
Install Pre-Formed Plan	1	0	1
Install Wallboard	2	2	2
Apply Mortar Pre-Slope (24 Hrs)	0	1	0
Install Liner and Final Slope (24 Hrs) Apply Sheet or Liquid Membrane 1st Coat (12 Hrs)	0	3	0
Install Banding (OR) Seaming w/ Thinset & Mesh	0	1	1
Install Corner Patches	0	0	1
Apply 2nd Coat Liquid Membrane (Wait 24 Hrs)	0	1	1
Apply 2nd Coat Liquid Membrane (Wait 24 Hrs)	0	1	0
Total Installation Hours	3	3	6
Water Test	IMMEDIATELY	24 HRS	24 HRS
Set Time (Waiting)	1 HOUR	48 HRS	24 HRS

